

VSDP – DIE Text Import – Creating a Virtuoso Layout from a 3rd party DIE text file

Product Version IC617_ISR19 and SPB172_17.20.037
May 18

Copyright Statement

© 2018 Cadence Design Systems, Inc. All rights reserved worldwide. Cadence and the Cadence logo are registered trademarks of Cadence Design Systems, Inc. All others are the property of their respective holders.

Contents

Purpose	4
Audience	4
Key Terms	4
Overview	4
Procedure	5
Summary	9
Support	9
Feedback	9

Purpose

IC Package designs have become more complex in recent years due to increased functional density & flexibility necessitating a platform for doing heterogeneous design assembly. A modern scheme for IC packaging includes implementing one or more die (wire bonded or flip-chip) with any number of discrete components (SMD or embedded) onto a single BGA/LGA package substrate. Cross-domain planning & optimization is now mandatory in early stages of the design flow.

Unification of the Virtuoso and Allegro/Sigrity platforms enables top-down design flows for complex IC package designs. This unified environment, now called **VSDP**, has the ability to define and manage system level connectivity as well as bidirectional Die abstract exchange.

VSDP has a functionality to bridge the 3rd Party DIE file to VLS. This can be done by VSDP Import Die Text File function to import a non-Virtuoso (3rd party) Die data text file into Virtuoso Layout. The requirements for the Die text file are Die size, Pin labels/names & X, Y placement coordinates

Audience

This document is intended for Module Designers involved with implementing complex multi-die/multi-technology module designs.

Key Terms

VSDP Virtuoso System Design Platform

VSE Virtuoso Schematic Editor

SiP System in Package

Overview


Note: This App Note introduces the basic steps on how to bridge the 3rd Party DIE file to Virtuoso Layout.

Note: For this App Note the assumption is that the user has the basic knowledge of Virtuoso Layout.

Procedure


Step 1: Create a new Virtuoso Layout:

- Make sure to set the following environmental variable to enable the menu option for Import Die Text File: `setenv CDS_CHIPS_IN_BASECELL 1`
- Open Virtuoso >>> `virtuoso -sdp`
- Create a new library or use an existing library to create a new layout view
 - Tools > Library Manager > File > New > Library
 - Tools > Library Manager > File > New > Cell View > Layout



- Once your Virtuoso Layout view is created, enable SDP option under Launch menu (Launch > SDP)
- From the SDP menu, double click on Import Die Text File

- In the Import Die Text File, Browse to the location of your Die Text File
- You also have the option to import csv file, for which you would need to choose Comma (“,”) as the Delimiter
- You also have the option to change your Pad Width as you wish (unit: Microns)




- Once ready, press ok to this form to continue to the layout of the Die
- As you can see in the pictures below, you could correlate the Die text file to the newly created layout view of the Die.

VSDP – Implementation Flow - Virtuoso Schematic to SiP Layout


```
File Edit Tools Syntax Buffers Window Help
[Icons]
DIE_COMPONENT: true
DieType: flipchip
DieOrient: ChipUp
Units: microns
Name: flipchip
Origin: (0.0 0.0)
Extents: ((-50.000 -50.000) (1050.000 1050.000))
Dimension: ((1100.000 1100.000)) Scribewidthx: 50.000000 Scribewidthy: 50.000000 ShrinkFactor: 1.00
Pin Name      X      Y
vss           50.000  950.000
tx_sub        350.000 650.000
modex         350.000 950.000
vss           650.000 950.000
pa_hdd        950.000 950.000
vdd           650.000 650.000
pa_gnd        950.000 650.000
q1            650.000 374.300
dtx           950.000 374.300
vss           950.000 50.000
tx_0          650.000 50.000
tx_1          350.000 50.000
vss           50.000 50.000
vdd           350.000 374.300
rx_1          50.000 374.300
rx_0          50.000 650.000
~
```

Die Text File

the minimum requirements



- You could view or modify the certain attributes and properties attached to the pin pads by selecting and pressing “q” to open the Edit Properties windows as it’s shown in below pictures



- Once you are done, press OK to exit the form

Summary

In this Application Note, the process of bridging the 3rd Party DIE file to Virtuoso Layout was covered.

Support

Cadence Online Support provides access to support resources, including an extensive knowledge base, access to software updates for Cadence products, and the ability to interact with Cadence Customer Support. Visit <http://support.cadence.com>.

Feedback

Email comments, questions, and suggestions to content_feedback@cadence.com.